



Flush tray subassemblies for the Glass Border version of 1500 Series steplight.



STEP 1 Pour the RIS into concrete wall, making front surface of tray flush with form.



STEP 2 Once concrete is dry, remove form.



STEP 3 Remove MDF pour support plate.



Flush trays shown with pour support plates removed.



STEP 4 Remove temporary cover plate label.





Flush trays shown with temporary cover labels removed.



STEP 5 Remove internal support plate.



STEP 6 Remove internal support plate - 2nd photo.



STEP 7 Remove vertical pour support plate.



STEP 8 Install Performance Optic Package (PoP).



STEP 9 Install Glass Border door assembly (GAS).

